


Spare Parts Catalog — TL6000 MX(KOMODO MX)


FIGURE-01 ■FRAME■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
1-1	11434-56000-000	■■■■■■■■■■M6x16	Bolt M6x16		Pcs	5
1-2	43101-56D00-002	■■■■■■■	Seat Front Fixing Clip		Pcs	1
6.25■■■■■		1-2-1	10723-56005-000	■■■■A■GB/T 97.1 Φ6xΦ12x2.0	GB/T 97.1 Φ 6xΦ12x2.0	
1-3	11431-56000-000	■■■■■■■■■■M6x10	Bolt M6x10		Pcs	2
1-4	43356-54001-008	■■■■■■■TL3000YS/■■■■■	Harness Assy. Fixing Plate		Pcs	2
1-5	12132-56D00-000	■■■■■■■	Battery Front Upper Limit Rubber		Pcs	1
1-6	11147-56000-000	■■■■■■■■■■M6x12	Bolt M6x12		Pcs	4
1-7	12122-56D00-000	■■■■■■■PA66■■■■■/■■■■■	L.Battery Pack Holder Rubber (PA66 /Black)		Pcs	1
1-8	11209-56000-000	■■■■■■■■■■M5x14	Screw M5x14		Pcs	6
1-9	12123-56D00-000	■■■■■■■PA66■■■■■/■■■■■	R.Battery Pack Holder Rubber (PA66 /Black)		Pcs	1
1-10	12135-56D00-000	■■■■■■■	Battery L. Limit Rubber		Pcs	1
1-11	12137-56D00-000	■■■■■■■	Battery R. Limit Rubber		Pcs	1
1-12	43356-54000-000	■■■	Clip		Pcs	1
1-13	11417-56000-000	■■■■■■■■■■M5x10	Bolt M5x10		Pcs	1
1-14	13071-56D00-000	■■■■■TL6000YS/■■■■■/φ14x3	Guide Wheel Axle(φ14x3)		Pcs	1
1-15	13386-56D00-000	■■■■■■■φ19.5x2■■φ12x6■■φ8x8	Guide Wheel Axle Bushing (φ19.5x2■■φ12x6■■φ8x8)		Pcs	1
1-16	12633-56D00-000	■■■■■TL6000YS	Chain Guide Wheel		Pcs	1
1-17	13385-56D00-000	■■■■■■■TL6000YS/φ8xφ12x8	Charin Guide Wheel Axle Liner Tube(φ8xφ12x8)		Pcs	1
1-18	13228-56D00-000	■■■■■■■TL6000YS/■■■608/φ8xφ22x7/■■■■■	Bearing 608■■φ8xφ22x7/Anti-Dust Cap■		Pcs	1
1-19	12133-56D00-000	■■■■■■■	FrontBattery Lower Limit Rubber		Pcs	1
1-20	52032-56D00-000	■■■■■TL6000YS	VIN Plate		Pcs	1


Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
1-21	12632-56D00-000	■■■■■■■	Chain Bottom Guard Board		Pcs	1
6.28■■■		1-22	11207-56000-000	■■■■■■■■■■■ M5x10	Bolt M5x10	
1-23	12127-56D00-000	■■■■■■■	Battery Bottom Rubber		Pcs	2
1-24	50010-56D00-000	■■■■	Harness		Pcs	1

FIGURE-02 ■■■ MOTOR & GEARBOX ASSY ■■■




Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
2-1	22077-56D00-000	■■■■■■■TL6000YS	Bolt	0	Set	1
2-2	22090-56D00-002	■■■■■TL6000YS	Driving Sprocket		Pcs	1
2-3	10315-56001-000	■■■■■■■■■■■	Screw		Pcs	3
2-4	43846-56D00-002	■■■■■■■■■TL6000YS	Gearbox Reinforcing Holder		Pcs	1
2-5	13236-56000-000	■■■■■GB/T 119.2-2000 Φ8x30■	Cylindrical pin ■GB/T 119.2-2000 Φ8x30■		Pcs	2
2-6	11459-56000-000	■■■■■■■■■■■■■■■■■■■■M8x25	Bolt M8x25		Pcs	7
2-7	10704-56000-000	■■■■■GB/T 93-1987 M8■Φ8xΦ16x1.5■	Spring Washer GB/T 93-1987 M8■Φ8xΦ16x1.5■		Pcs	7
2-8	10724-56000-000	■■■■■A■GB/T 97.1 Φ8xΦ16x1.5	Washer A Rank GB/T 97.1 Φ8xΦ16x1.5		Pcs	7
2-9	11455-56000-000	■■■■■■■■■■■■■■■■■■■■M8x16	Bolt M8x16		Pcs	2
2-10	43849-56D00-002	■■■■■■■TL6000YS	Gearbox Holder		Pcs	2
2-11	11491-56000-000	■■■■■■■■■■■■■■■■■■■■M10x70■P=1.25■	Bolt M10x70■P=1.25■		Pcs	1
2-12	10044-56001-000	■■■■■■■■■■■■■■■■■■■■■-■■■M10x1.25	Nut M10x1.25		Pcs	1
2-13	31356-56D00-000	■■■TL6000YS/520-108■	Chain (520-108)		Pcs	1
2-14	22000-56D00-000	■■■■■■■	Gearbox Assy.		Set	1
2-15	22082-56000-000	■■■■■■■■■■■■■■■■■■■■not selling	Gas Vent Valve not selling		Pcs	1
2-16	22083-56000-000	■■■■■	Clip		Pcs	1
2-17	22085-56D00-000	■■■■■Φ9xΦ5x265■	Rubber Hose ■Φ9xΦ5x265■		Pcs	1
2-18	22086-56000-000	■■■■	Gearbox tube clip		Pcs	1
2-19	22087-56000-000	■■■■	Waterproof Cap		Pcs	1

FIGURE-03 ■ GEARBOX ASSY. ■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
3-1	50020-56D00-000	■■■■■	Battery Pack Discharge Cable		Pcs	1
3-2	20000-56D00-000	■■	Motor		Pcs	1
3-3	11434-56000-000	■■■■■■■■■■ M6×16	Bolt M6×16		Pcs	4
3-4	10572-56000-000	■■■DIN912■■■■■■■■ M6×14	Bolt M6		Pcs	5
3-5	24000-56D00-000	■■■	Controller		Pcs	1
3-6	20001-56D00-000	■■■■■■■■■■■■■■■■■■■■	Magnetic Encoder		Pcs	1
3-7	24090-54000-000	■■■■■■■■■■■■	Controller waterproof rubber sleeve(red)		Pcs	4
3-8	24090-54001-000	■■■■■■■■■■(■■■)	Controller waterproof rubber sleeve(black)		Pcs	1


FIGURE-04(FRAME ASSY.■)



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
4-1	11417-56000-000	■■■■■■■■■■M5x10	Bolt M5x10		Pcs	7
4-2	50400-56D00-000	■TL6000YS	Key Switch		Set	1
4-3	32841-56D00-000	■■■■■TL6000YS	Key Switch Decoration Cover		Pcs	1
4-4	40010-56D00-001	■TL6000YS(■)	Frame (un-painting)		Pcs	1
40010-56D00-002	■TL6000YS■■■■■	Frame (Black Painting)		Pcs	1	
40010-56D00-019	■TL6000YS■■■■■	Frame (Blue Painting)		Pcs	1	
40010-56D00-026	■TL6000YS■■■■■	Frame (Green Painting)		Pcs	1	
4-5	10094-56000-000	■■■■■■■■■■DIN6923-1983 M6	Nut M6		Pcs	2
stop using		4-6	50170-56D00-000	■■■■■TL6000YS	Tip-Over Sensor	
4-7	11437-56000-000	■■■■■■■■■■M6x22	Bolt M6x22		Pcs	2
4-8	50070-56D0Z-000	■■■■■TL6000YS	Horn		Set	1
4-9	10726-56000-000	■■■■A■GB/T 97.1 Φ6xΦ16x1	Washer GB/T97.1 (M6)		Pcs	1
4-10	11434-56000-000	■■■■■■■■■■ M6x16	Bolt M6x16		Pcs	1
4-11	32851-56D00-000	■■■■■TL6000YS	Horn decoration cover		Pcs	1
4-12	32893-56D00-000	■■■■■TL6000YS	Battery pack backboard		Pcs	1
4-13	11207-56000-000	■■■■■■■■■■M5x10	Screw M5x10		Pcs	2
4-14	43416-56D00-000	■■■■■■■■■TL6000YS	L. Battery backboard support		Pcs	1
4-15	43417-56D00-000	■■■■■■■■■TL6000YS	R. Battery backboard support		Pcs	1
4-16	11282-56000-000	■■■■■■■■■■M6x12	Screw M6x12		Pcs	2

Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
4-17	32921-56D00-000	■■■■■■■TL6000YS	Driving Sprocket protect cover		Pcs	1
4-18	11430-56000-000	■■■■■■■■■■M6x8	Bolt M6x8		Pcs	2

FIGURE-05(FRAME ASSY.■)




Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
5-1	11434-56000-000	■■■■■■■■■■ M6x16	Bolt M6x16		Pcs	4
5-2	13233-56D00-000	■■■■■■■	Front fender liner		Pcs	4
5-3	32010-56D00-000	■■■■■■■■■	Front fender(black)		Pcs	1
32010-56D00-008	■■■■■■■■■	Front fender(white)		Pcs	1	
5-4	11282-56000-000	■■■■■■■■■■M6x12	Screw M6x12		Pcs	1
5-5	32020-56D00-000	■■■■■■■■■	Front No. plate(black)		Pcs	1
32020-56D00-008	■■■■■TL6000YS/■■■■■	Front No. plate(white)		Pcs	1	
5-6	43356-54000-000	■■■	Clip		Pcs	1
5-7	11417-56000-000	■■■■■■■■■■ M5x10	Bolt M5x10		Pcs	1

FIGURE-06 ■ BATTERY PACK HOLDER ■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
6-1	32931-56D00-000	■■■■■TL6000YS	Motor protection board		Pcs	1
6-2	11431-56000-000	■■■■■■■■■■M6x10	Bolt M6x10		Pcs	2
6-3	11457-56000-000	■■■■■■■■■■M8x20	Bolt M8x20		Pcs	2
6-4	43952-56D00-000	■■■■■TL6000YS	motor protection board support		Pcs	1
6-5	43961-56D00-002	■■■■■TL6000YS	Gearbox protection board support		Pcs	1
6-6	12141-56D00-000	■■■■■TL6000YS	Motor buffer rubber		Pcs	1
6-7	43847-56D00-002	■■■■■■■■	Gearbox protection board brace		Pcs	1
6-8	11434-56000-000	■■■■■■■■■■M6x16	Bolt M6x16		Pcs	2
6-8	11438-56000-000	■■■■■■■■■■M6x25	Bolt M6x25		Pcs	2


FIGURE-7 ■ ELECTRICAL PARTS ■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
7-1	41010-56D00-000	■■■■■TL6000YS	Seat Assy.		Pcs	1
7-2	41012-56D00-000	■■■■■TL6000YS	Seat fixing support		Pcs	1
7-3	11147-56000-000	■■■■■■■■■■■■■■■■■■■■M6×12	Screw M6×12		Pcs	3
7-4	10552-56D00-000	■■■■■TL6000YS	Battery Pack Cover Axle		Pcs	2
7-5	32882-56D0Z-000	■■■■■■■■■■■■■■■■■■■■/■■■	Under Seat Forepart assy.(Black)		Set	1
32882-56D0Z-008	■■■■■■■■■■■■■■■■■■■■/■■■	Under Seat Forepart assy.(White)		Set	1	
7-6	11149-56000-000	■■■■■■■■■■■■■■■■■■■■M6×16	Screw M6×16		Pcs	2
7-7	11356-56000-000	■■■■■■■■■■■■■■■■■■■■M6×10	Screw M6×10		Pcs	2
7-8	32431-56D00-000	■■■■■TL6000YS■■■■■■■■■■	Rear Fender(Black)		Pcs	1
32431-56D00-008	■■■■■TL6000YS/■■■■	Rear Fender(White)		Pcs	1	
7-9	43784-56D00-002	■■■■■TL6000YS	Seat lock bracket		Pcs	1
7-10	13384-56D00-000	■■■■■■■	Seat lock liner tube		Pcs	1
7-11	43785-56D00-000	■■■■■	Seat lock		Pcs	1
7-12	11453-56000-000	■■■■■■■■■■■■■■■■■■■■M8×12	Bolt M8×12		Pcs	2
7-13	11455-56000-000	■■■■■■■■■■■■■■■■■■■■M8×16	Bolt M8×16		Pcs	2
7-14	11282-56000-000	■■■■■■■■■■■■■■■■■■■■M6×12	Bolt M6×12		Pcs	2
7-15	40300-56D00-001	■■■■■TL6000YS■■■■■■■■■■	Seat Holder (Un-painting)		Pcs	1
40300-56D00-002	■■■■■TL6000YS■■■■■■■■■■	Seat Holder (Black)		Pcs	1	
40300-56D00-019	■■■■■TL6000YS■■■■■■■■■■	Seat Holder (Blue)		Pcs	1	


Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
40300-56D00-026	■■■■TL6000YS■■■■■	Seat Holder (Green)			Pcs	1
7-16	11417-56000-000	■■■■■■■■■■■■■■■■■■■■M5x10	Bolt M5x10		Pcs	2
7-17	10611-56000-000	■■■■GB/T 845 ST4.8x13	Screw GB/T845■ST4.8*13)		Pcs	1
7-18	43411-56D00-002	■■■■■■■■■■	Rear Fender Reinforcing Holder		Pcs	1
7-19	12126-56D00-000	■■■■■■■■	Battery Pack Holder Cover Buffer Gasket		Pcs	1
7-20	11149-56000-000	■■■■■■■■■■■■■■■■■■■■ M6x16	Screw M6x16		Pcs	2
7-21	12129-56D00-000	■■■■■	buffer rubber		Pcs	4

FIGURE-9 ■ Handlebar Assy. ■




Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
9-1	35250-56000-000	■■■■	L.Handlebar Grip		set	1
9-2	50391-56D00-000	■■■■■■■■■■	Left Switch(two in one)		Pcs	1
9-3	50300-56D00-000	■■■■■■■	Dash		Pcs	1
9-4	35200-56D00-002	■■■■	Handlebar		Pcs	1
9-5	11459-56000-000	■■■■■■■■■■/M8x25	Bolt M8x25		Pcs	4
9-6	35242-56D00-002	■■■■■	Handlebar upper cover		Pcs	2
9-7	35232-56D00-002	■■■■■	Handlebar Base		Pcs	2
9-8	50180-56D00-000	■■■■■	Throttle		Pcs	1
6.25■■■		9-9	50181-56D00-000	■■■■■	Magnetic Switch	
9-10	50078-56D00-000	■■■■■■■	regen button		Pcs	1
9-11	35220-56000-000	■■■■■	Handlebar stopper		Pcs	2

FIGURE-10 ■ Front Fork ■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
10-1	13557-56D00-002	■■■■■■TL6000YS	Front Fork lock nut		Pcs	1
10-2	13556-56D00-002	■■■■■■■	Front Fork Adjusting nut		Pcs	1
10-3	13512-56D00-002	■■■■■■■	Steering dust cover		Pcs	1
10-4	12553-56000-000	O■■■■■TL6000YS/φ27.3×1.8	O-ring		Pcs	1
10-5	12554-56000-000	O■■■■■TL6000YS/φ58×2.65	O-ring		Pcs	1
10-6	13213-56000-000	■■■■■32906	Front Fork Bearing		Pcs	2
10-7	13555-56000-000	■■■■■■■TL3000YSφ46×φ30×2.5	Front Fork Bearing Washer		Pcs	1
10-8	43535-56000-000	■■■■■■■	Front Fork Adjusting Spacer(Φ42-Φ30-0.5)		Pcs	2


FIGURE-12 Front Wheel Assy.



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
12-1	31010-56D00-000	■■■■■	Front wheel assy.		Set	1
12-2	31011-56D00-002	WM■■■■■1.6*21	Rim 1.6*21		Pcs	1
12-3	31028-56D00-000	■■■■■M3.6*0.6■■31029-56D01-000■	Spoke Nut M3.6*0.6		SET	36
■■■■Φ3.2-Φ3.5 5■■31028-56D02-000■		outer SpokeΦ3.2-Φ3.5		18		
■■■■Φ3.2-Φ3.5 5■■31028-56D01-000■		Inner SpokeΦ3.2-Φ3.5		18		
12-4	31021-56D0Z-002	■■■■■	Front Hub Assy.		Set	1
12-5	31012-56D00-000	■■■■■Φ26*Φ37*6	Oil seal Φ26*Φ37*6		Pcs	2
12-6	13212-56D00-000	■■■■■61904-2RS■■37*20*9■	Bearing		Pcs	2
7.3■■■		12-7	31021-56D00-002	■■■	Front wheel hub	
12-8	31013-56D00-000	■■■■■Φ26*67.5	Front wheel hub inner liner tube		Pcs	1
12-9	31027-56D00-000	■■■■■	Front wheel R. liner		Pcs	1
12-10	31307-56D00-000	■■■■■	Front tyre(E-Mark)		Pcs	1
31307-56D01-000	■■■■■	Front tyre(NO E-Mark)		Pcs	1	
31308-56D01-000	■■■■■CST	Front tyre(NO E-Mark) CST		Pcs	1	
12-11	31325-56D00-000	■■■■■	Front inner tube(E-Mark)		Pcs	1
31325-56D01-000	■■■■■	Front inner tube(NO E-Mark)		Pcs	1	
31325-56D03-000	■■■■■CST	Front inner tube(NO E-Mark) CST		Pcs	1	
12-12	31343-56D00-000	■■■■■	Rim band		Pcs	1

Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
12-13	35470-56D00-000	■■■	Disc		Pcs	1
12-14	10635-56000-000	■■■■■■■	Screw		Pcs	6
12-15	31026-56D00-000	■■■■■■■	Front Wheel L. Liner		Pcs	1


FIGURE-13 Rear Wheel Assy.)



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
13-1	31130-56D00-000	■■■■■	Rear wheel assy.		Set	1
13-2	31153-56D00-000	■■■Φ3.5*192■■31153-56D01-000■	Inner SpokeΦ3.5*192		Set	18
■■■Φ3.5*192 2■■31153-56D02-000■	outer SpokeΦ3.5*192			18		
■■■■■M4*0.7 ■■31029-56D02-000■	Spoke Nut M4*0.7			36		
13-3	31156-56D00-002	WM■■■■■■■2.15*18	Rim 2.15*18		Pcs	1
13-4	31135-56D0Z-002	■■■■■	Rear Hub Assy.		Set	1
13-5	31132-56D00-000	■■■Φ26*42*6	Oil seal Φ26*42*6		Pcs	2
13-6	13223-56001-000	■■■6004-2RS■■42*20*12■	Bearing		Pcs	3
13-7	31134-56D00-000	■■■6004	Support ring		Pcs	2
13-8	31135-56D00-002	■■■	Rear Hub		Pcs	1
13-9	31145-56D00-000	■■■Φ26*94	liner		Pcs	1
13-10	31372-56D00-002	■■■	Sprocket	25-30N.m	Pcs	1
13-11	10317-56000-000	■■■■■■■■■M8x19■■■φ10■■■4.5■	Screw M8x19		Pcs	6
13-12	13171-56D00-000	■■■■■	Rear Wheel R. Liner		Pcs	1
13-13	31315-56D00-000	■■■■■■■■■90/100-18	Rear tyre(E-Mark)		Pcs	1
31315-56D01-000	■■■■■■■■■90/100-18	Rear tyre(NO E-Mark)		Pcs	1	
31316-56D01-000	■■■■■■■■■CST110/90-18	Rear tyre(NO E-Mark) CST		Pcs	1	
13-14	31335-56D00-000	■■■■■■■■■	Rear inner tube(E-Mark)		Pcs	1
31335-56D01-000	■■■■■■■■■	Rear inner tube(NO E-Mark)		Pcs	1	


Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
31336-56D01-000	■■■■■■■■■CST	Rear inner tube(NO E-Mark) CST	50-60N.m	Pcs	1	
13-15	31344-56D00-000	■■■■■■■■■	Rim band(rear tyre)		Pcs	1
13-16	35591-56D00-000	■■■■■	Rear Disc		Pcs	1
13-17	10635-56000-000	■■■■■■■■■	Screw		Pcs	6
13-18	13151-56D00-000	■■■■■	Rear Wheel L. Liner		Pcs	1
13-19	13191-56D00-000	■■■■	Rear Wheel Axle		Pcs	1

FIGURE-14 Rear Suspension Assy.




Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
14-1	11489-56000-000	■■■■■■■■■■M10x55	Bolt M10x55		Set	1
14-2	42600-56D00-000	■■■■TL6000YS■■■■■	Rear shock absorber(black)		Pcs	1
42600-56D00-006	■■■■TL6000YS■■■■■	Rear shock absorber(gold)		Pcs	1	
14-3	10044-56001-000	■■■■■■■■■■■-■■■■M10x1.25	Nut M10x1.25		Pcs	3
14-4	11486-56000-000	■■■■■■■■■■M10x40	Bolt M10x40		Pcs	1
14-5	12657-56D00-000	■■■■■22xφ16x4	oil seal		Pcs	6
14-6	13217-56D00-000	■■■■■TL6000YSφ22xφ16x12	Swinging Arm Lower Bearing		Pcs	1
14-7	42812-56D00-000	■■■■■TL6000YSφ16xφ10x21	Rear shock absorber lower liner tube		Pcs	1
14-8	11517-56000-000	■■■■■■■■■■M12x75	Bolt M12x75		Pcs	1
14-9	12656-56D00-000	■■■■■24xφ18x4	oil seal		Pcs	2
14-10	13219-56D00-000	■■■■■	Swinging Arm Upper Bearing		Pcs	2
14-11	42800-56D00-002	■■■■TL6000YS	Swinging Arm		Pcs	1
14-12	42802-56D00-000	■■■■■φ18xφ12x43	Swinging Arm Upper liner tube		Pcs	1
14-13	10045-56001-000	■■■■■■■■■■■-■■■■M12x1.25	Nut M12x1.25		Pcs	1
14-14	11493-56000-000	■■■■■■■■■■M10x80	Bolt M10x80		Pcs	1
14-15	13218-56D00-000	■■■■■φ22xφ16x16	Swinging Arm Linkage Bearing		Pcs	4
14-16	42801-56D00-000	■■■■■φ16xφ10x43	Swinging Arm Lower Bearing		Pcs	1
14-17	11497-56000-000	■■■■■■■■■■M10x100	Bolt M10x100		Pcs	1
14-18	42700-56D00-002	■■■■TL6000YS	Swinging Arm Linkage		Pcs	1
14-19	42701-56D00-000	■■■■■φ16xφ10x68	Swinging Arm Linkage Liner tube		Pcs	1
14-20	42800-56D0Z-000	■■■■■	Swinging Arm Assy.		Set	1

FIGURE-15 ■ Rear FORK ASSY.




Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
15-1	13051-56D00-000	■■■■TL6000YS /■■■■	Rear Fork Shaft		Pcs	1
15-2	13371-56D00-000	■■■■■■ TL6000YS	Rear Fork Shaft Liner		Pcs	4
15-3	12658-56D00-000	■■■■■ TL6000YSφ32xφ25x7	oil seal		Pcs	4
15-4	13220-56D00-000	■■■■■ TL6000YS/■■■HK2010/φ26xφ20x10	Rear Fork Bearing		Pcs	4
15-5	13372-56D00-000	■■■■■■φ15xφ20x42	Rear Fork Shaft Liner Tube		Pcs	2
15-6	40430-56D00-002	■■■TL6000YS/■■■	Rear Fork(black)		Pcs	1
15-7	43537-56D00-000	■■■■■■φ20xφ31.5x1	Rear Fork Shaft Spacer		Pcs	2
15-8	10683-56000-000	■■■■■GB/T 1972Φ14xφ28x0.9	spring		Pcs	1
15-9	10493-56000-000	■■■GB 812-1988 M14x1.5	Nut M14x1.5		Pcs	1
15-10	12631-56D00-000	■■■■■■TL6000YS	Chain Upper Guard Board		Pcs	1
15-11	11209-56000-000	■■■■■■■■■■■■■■■■■■M5x14	Screw M5x14		Pcs	2
15-12	43661-56D00-002	■■■■■■■■TL6000YS	Rear Fork Decoration Stopper		Pcs	1
15-13	43010-56D00-000	■■■TL6000YS	Rear Chain box		Pcs	1
15-14	11282-56000-000	■■■■■■■■■■■■■■■■■■M6x12	Screw M6x12		Pcs	2
15-15	11436-56000-000	■■■■■■■■■■■■■■■■■■M6x20	Bolt M6x20		Pcs	2
15-16	43692-56D00-000	■■■TL6000YS	Chain guide		Pcs	1
15-17	13563-56D00-000	■■■■■■M8■■■■10x7■	Nut M8		Pcs	2
15-18	13562-56D00-000	■■■■■■■■	Chain Tensioner Bolt		Pcs	2
15-19	43671-56D01-002	■■■■■■■■	L. Chain Tensioner		Pcs	1
15-20	43671-56D02-002	■■■■■■■■	R. Chain Tensioner		Pcs	1

FIGURE-16 ■ LBN BRAKE ASSY ■




Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
16-1	35450-56D00-000	■■■■■	Front brake assy.		Pcs	1
16-2	35460-56D00-000	■■■■■■■	Front Brake Upper Pump Assy.		Pcs	1
16-3	35461-56D00-000	■■■■■	Front brake lever		Pcs	1
16-4	35469-56D01-000	■■■■■■■	FrontBrake Power Cut-Off Cable		Pcs	1
16-5	35459-56D00-000	■■■■■■■■■1150mm	Front brake oil tube 1150mm		Pcs	1
16-6	35451-56D00-000	■■■■■■■	Front brake clip assy.		Pcs	1
16-7	35453-56D00-000	■■■■■■■■■/■■■	Front brake pad(left and right)		Set	1
16-8	35530-56D00-000	■■■■■	Rear brake assy.		Set	1
16-9	35540-56D00-000	■■■■■■■	Rear Brake Upper Pump Assy.		Pcs	1
16-10	35541-56D00-000	■■■■■	Rear brake lever		Pcs	1
16-11	35469-56D02-000	■■■■■■■	RearBrake Power Cut-Off Cable		Pcs	1
6.13■■■■■		16-12	35551-56D00-000	■■■■■■■■■1600mm	Rear brake oil tube 1600mm	
16-13	35532-56D00-000	■■■■■■■	Rear brake clip assy.		Set	1
16-14	35533-56D00-000	■■■■■■■■■/■■■	Rear brake pad(left and right)		Set	1

FIGURE-17 ■ Footpeg Assy. ■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
17-1	43644-56D00-000	■■■■	Footpeg axle		Pcs	2
17-2	40622-56D00-002	■■■■■	L. Footpeg Holder		Pcs	1
17-3	11436-56000-000	■■■■■■■■■■	Bolt		Pcs	2
17-4	40620-56D00-002	■■■■■TL6000YS/■■■■■■	L. Footpeg(black)		Pcs	1
17-5	11802-56000-000	■■■■■	Footpeg Spring		Pcs	2
17-6	10724-56000-000	■■■■■A	Washer GB/97.1(M8)		Pcs	2
17-7	10782-56000-000	E■■■■/Φ6	Circlip (inner diameter Φ6)		Pcs	2
17-8	11455-56000-000	■■■■■■■■■■/M8×16	Bolt M8×16		Pcs	2
6.28■■■		17-9	11459-56000-000	■■■■■■■■■■/ M8×25	Bolt M8×25	
17-10	40324-56000-000	■■■■■	Side Kickstand axle		Pcs	1
17-11	10043-56000-000	■■■■■■■■■■■■■■■■■■■■/M8×1.25	Bolt GB/T6187.1(■M8)		Pcs	1
17-12	11402-56000-000	■■■■■■■■■■	Side Kickstand Spring		Pcs	1
17-13	40327-56000-000	■■■■■■■■■■	Side Kickstand Spring Pin		Pcs	2
17-14	40320-56D00-002	■■■■■	Side Kickstand		Pcs	1
17-15	40650-56000-000	■■■■■■■■■■	Footpeg Holder Braces		Pcs	1
17-16	40642-56D00-002	■■■■■	R. Footpeg Holder		Pcs	1
17-17	40640-56D00-002	■■■■■TL6000YS/■■■■■■	R. Footpeg(black)		Pcs	1
17-18	50200-56D00-000	■■■■■■■	Side Kickstand Sensor		Pcs	1
17-19	10344-56000-000	■■■■■■■■■■/M3×10	Bolt M3×10		Pcs	1

FIGURE-18 ■ Decal Kit ■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
18-1	50040-56D05-000	■■■■■■■■ TL6000YS/96V15A	EU charger(TianLi)		Pcs	1
50040-56D14-000	■■■■■■■■ TL6000YS/96V15A	Charger(AU230V)96V15A		Pcs	1	
50040-56D12-000	■■■■■■■■ TL6000YS/96V15A	Charger(Brazil)96V15A		Pcs	1	
50040-56D09-000	■■■■■■■■ TL6000YS/96V15A	Charger(US110V)96V15A		Pcs	1	
50040-56D07-000	■■■■■■■■ TL6000YS/96V15A	Charger(UK230V)96V15A		Pcs	1	
18-2	11445-56000-000	■■■■■■■■■■ M6x55	Bolt M6x55		Pcs	2
18-3	11448-56000-000	■■■■■■■■■■ M6x70	Bolt M6x70		Pcs	1
18-4	12121-56D00-000	■■■■■■■	Battery pack fixing rubber pad		Pcs	3
18-5	23000-56D00-000	■■■■■	Battery pack		Pcs	1

FIGURE-19 ■ Decal Kit ■

TALARA

Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
19-1	52134-56D00-000	■■	Trademark		Set	1
19-2	52010-56D00-000	■■■■■	Whole set warning lable		Pcs	1
19-3	52013-56000-000	■■■■	High pressure lable		Pcs	2
19-4	52017-56000-000	■■■■■	Gearbox gas vent clip lable		Pcs	1
19-5	52011-56A02-000	16■■■■■■■■■■	No ridding under 16 years old lable		Pcs	1
19-6	52011-56D00-000	■■■■■	Warning lable		Pcs	1
19-7	52012-56D00-000	■■■■■	Tyre pressure lable		Pcs	1
19-8	52032-56D00-000	■■■■■TL6000YS	VIN Plate		Pcs	1

FIGURE-20 ■ Footpeg Assy&Warbing; Sticker ■



Item	Ref. No.	Description (CN)	Description (EN)	Torque	Unit	Qty
20-1	52051-56D00-000	■■■■■	Tool Kit		Set	1
20-2	22071-56A00-000	■■■■GL-5 85W-90	Gear oil		Pcs	1